



Simply beautiful, on or off

The controls and zones of the stylish Pure hob appear only when you need them. When not in use, the hob's sleek surface is designed to blend seamlessly into your worktop. When you're ready to create culinary magic, a touch will activate the hob, revealing its settings and functions.

Product Benefits & Features

A modern hob, beautifully designed

A sleek black surface when it's turned off, the hob blends seamlessly into your kitchen counter. The hob's controls are illuminated at a touch, displaying stylish windmill designs in the cooking zones. Our elegant hob is the perfect addition to a modern kitchen.



Merge zones for more room to cook with the Bridge function

The Bridge function lets you combine two separate cooking zones to create a single large surface. With the temperature and time settings automatically aligned, it's ideal for making the most of planchas or roasting pots.



Hob2Hood® for pure convenience

The Hob2Hood® function wirelessly connects your hob to your hood. Start cooking and the hood will automatically adjust the settings, providing the best extraction based on the power selected on the hob. It does the hard work so you can keep your mind – and your hands – on your cooking.



- Hob type: Induction
- Hob with bevelled frame
- Controls position: Front Middle
- Illuminated controls
- Digital indications for each zone
- Induction zones with power booster function
- Pot detection
- Left front zone: Induction, 2300/3200W/180x210mm
- Left rear zone: Induction, 2300/3200W/180x210mm
- Middle front zone: No, 0W/0mm
- Middle rear zone: No, 0W/0mm
- Right front zone: Induction, 2300/3200W/180x210mm
- Right rear zone: Induction, 2300/3200W/180x210mm
- Key-lock function
- Child safety lock function
- Acoustic signal with switch off option
- EcoTimer™
- Timer function
- CleverHeat™ function
- Easy installation thanks to snap-in system
- Main colour: Black

Cooking zones light up with ActiveTouch

When you place your pan on the hob the corresponding slider control automatically illuminates. So you know intuitively which control to use for your cooking. Simply select the desired temperature for your dish with the swipe of your finger, and you'll enjoy delicious results, quickly.

Every zone individually timed

Cooking multiple dishes can be complex, but setting timers shouldn't be. Set individual timers for each cooking zone, and when the timer's finished the hob automatically shuts off. It's smart assistance so every meal comes together with ease.

Product Specification

Product Installation	Built_In	Depth cutting	490
Product Typology	Electric_Hob	Radius cutting	5
Product Classification	Statement	Fastening	Snap in System
Installation	Independent	Gas original	No
Size	60	Gas replacement 2	No
Hob type	Induction Full	Gas replacement 3	No
Design family	Electrolux 100	Gas category	No
Main colour	Black	Frequency	50-60
Control Panel material	Glass	Voltage	220-240V/400V2N
Frame type	Bevelled 1 Side	Cord length external	1.5
Frame material	No		
Knobs colour	No		
Top Control Place	Front Middle		
Type of controls	Cardinal, Electronic		
Control function	3 step residual heat, Acoustic signal, Booster, Child-lock, Eco timer, Hob-hood connection, Key-lock function, Left & Right Bridge, Minute minder, Pause, Sound off, Timer		
Other comments categorisation	ref. 949 596 927, Flame Retardant Project		
Width mm	590		
Depth mm	520		
Built in height mm	44		
Width cutting	560		