






SE 3/4 Karusell för bänkhörnskåp 90cm MDF
 DK 3/4 Karrusel for hjørneunderskab 90cm MDF
 NO 3/4 Karusell for hjørneskåp 90cm MDF
 FI 3/4 Karuselli kulmapöytäkaappiin 90cm MDF
 EN 3/4 Carousel for base corner 90cm MDF




Pots & Pans 3/4


E24009034009 E24009034007




1




2





3




4




5




6



7




8




i




18x



2x






2x




2x



9



i






UNLOCKED




LOCKED





10



i



UNLOCKED



LOCKED

11

